

INSTRUCTION SHEET

DISTRIBUTOR ADAPTER



INSTRUCTIONS

1. **CONNECT ADAPTER TO HARNESS**

This adapter connects a vehicle's wiring harness with a GM Weatherpack connector to a compatible distributor (e.g., MSD 85551).

2. **MATCH WIRE COLORS**

Align the **Green** and **Purple** wires from the vehicle's harness to the corresponding **Green** and **Purple** wires on the adapter.

3. **SECURE THE PINS**

- a. Insert the pins into the Weatherpack holster.
- b. Push each pin until you hear a "click," indicating that the pin is securely locked in place.
- c. Close the lock on the holster.

4. **INSTALL ADAPTER**

Once the lock is secured, plug the adapter in-line between the harness and the distributor.

5. **DOUBLE-CHECK ALIGNMENT**

Verify that the Green and Purple wires are correctly matched between the harness and adapter before starting the engine.



REV.11-24

⚠ WARNING: This product can expose you chemicals including lead, which is/are known to the state of California to cause cancer, birth defects or other reproductive harm. For more information, go to: www.P65Warnings.ca.gov

