

PART NO. 66-512

INSTRUCTION SHEET



TRAVEL INDICATOR

1. Place front tab in between preload nut and supplied jam.
2. Place rear tab in between pullbar housing and rear stud.
3. Align tabs and insert rod, threaded part towards back.
4. Tighten lock nuts on rod, put o-rings on either side of front tab.
5. Cut rod if it is too long for application.



REV.11-24

⚠ WARNING: This product can expose you chemicals including lead, which is/are known to the state of California to cause cancer, birth defects or other reproductive harm. For more information, go to: www.P65Warnings.ca.gov



www.quickcar.com
1-800-997-7333

170 Business Park Dr,
Lebanon, TN 37090