

INSTRUCTION SHEET

BASIC SWITCH PANEL WIRING HARNESS



- Ready to install.
- 5-foot length.
- Connects switch panel to starter.
- Accessory wires included.

NOTE: Disconnect battery before installing any wires to prevent injury/damage.

Route all wiring passing through any firewall/sheet metal with a protective grommet to prevent damage to the wires. For switch panels with lights, connect black wires to ground. It is common to use the bolts used for mounting the panel to do this.

BEFORE PLUGGING HARNESS AND SWITCH PANEL TOGETHER, CONNECT ALL WIRES AS FOLLOWS:




Yellow wire to starter post on solenoid.



Red wire to positive battery post on remote solenoid or starter.



Red wire w/ Black stripe to ignition switched +12V on ignition box, ECU, or HEI distributor.



White wire goes from the top of accessory switch to accessory (+12V).

**Due to different harness/switch panel options, ALL QuickCar switch panels and wiring harnesses are sold separately.*



WHITE WIRE 
FROM TOP OF ACCESSORY
SWITCH TO ACCESSORY

**RED WIRE
WITH BLACK STRIPE**
TO IGNITION SWITCHED +12V
ON IGNITION BOX, ECU, OR
HEI DISTRIBUTOR



RED WIRE
TO POSITIVE
BATTERY POST



YELLOW WIRE
TO STARTER POST
ON SOLENOID.

REV.10-24

⚠ WARNING: This product can expose you chemicals including lead, which is/are known to the state of California to cause cancer, birth defects or other reproductive harm. For more information, go to: www.P65Warnings.ca.gov



www.quickcar.com
1-800-997-7333

170 Business Park Dr,
Lebanon, TN 37090