# INSTRUCTION SHEET

# **DIGITAL TIRE GAUGE**



#### HOLD PEAK READING INSTEAD OF CONSTANT READING

- Hold "FUNC" until the #1 comes up, then release button.
- Press "FUNC" when Hold is displayed. Display will flash indicating change was accepted.

#### KEEP GAUGE ON OR TURN OFF AUTOMATICALLY

• The gauge is preset to turn off automatically after 180 seconds.

#### To have the gauge stay on:

- Hold "FUNC" until the #2 comes up, then release button.
- Press "FUNC" when Aon appears. The gauge is now on until turned off.

#### To adjust how long the gauge stays on when in Auto Off mode:

- Hold "FUNC" until the #2 comes up, then release button.
- Press the "FUNC" when AoF comes up, then press the "FUNC" to adjust the number of seconds down, and the On button to adjust the seconds up, then wait for setting to be accepted.

### READ IN PSI, BAR, KGF/CM2, OR KPA

- Hold "FUNC" until the #3 comes up, then release button.
- The selections will rotate at the bottom of the screen, press the "FUNC" when desired selection is on. PSI reading is what comes standard on the gauge.

## ADJUST GAUGE READING INCREMENTS

- Hold "FUNC" until the #4 comes up, then release button.
- The options are .1, .5, and .2; press the "FUNC" when desired amount is showing.
- This is only adjustable in the PSI readings; gauge comes standard in the .1 increments.

## ADJUST THE SPEED OF RESPONSE OF THE GAUGE

- Hold "FUNC" until the #5 comes up, then release button.
- There are 5 levels to choose from, the lower the number the faster. Press the "FUNC" when the desired number is on the screen. Gauge is preset at level 2.

REV.10-24

cancer, birth defects or other reproductive harm. For more information, go to: www.P65Warnings.ca.gov





📤 WARNING: This product can expose you chemicals including lead, which is/are known to the state of California to cause